Updated 2026-11-03

MotoCrane Revolt LED and Ronin 2 power

STATUS LED

Off: no power or reverse polarity

Strobing white: standby

Green 23 to 29V, yellow 22 to 23V, orange 21.5 to 22V, red 12 to 21.5V

Blinking red: over 29V

Blue blue green / red: Auto-On on / off

FIXES

Ronin 2 firmware 1.3.0.60 or 0.0.0.0 will not work. Use 1.7.1.00.

Arri polarity: pin 1 negative, pin 2 positive.

Ronin 2 will not start at 27.5V+: use the BBR (28V to 26V).

AC-3/DC-3 dead: breaker tripped. Check load, cycle switch.

Independent summary by Moving Shot. Not an official MotoCrane document and not affiliated with MotoCrane, LLC. Source: Revolt Operation Manual v1.1 at motocrane.com/knowledge-base. Always follow the current MotoCrane manual. MotoCrane Support: support@motocrane.com, +1 (612) 361-2325. Full guide: movingshot.com/knowledge/motocrane